


Read this first: Installing GT Mini

This diagram represents a GT Mini 3330 installation with a StarLeaf Touch and Microphone 0155. For more information and before installing StarLeaf GT Mini, read the safety and compliance information at support.starleaf.com/documentation

Camera (either the supplied PTZ or USB camera)

Power supply for camera



or



USB camera video-out

The selector on the rear of the PTZ camera must be correctly set. Refer to the camera documentation, or to the GT Mini documentation on www.starleaf.com

PTZ camera control (VISCA In)

PTZ camera video-out


Configuration

To configure audio, display, and other settings, go to <https://portal.starleaf.com>


StarLeaf Touch



Power




Amplifier and loudspeakers (Optional)



Microphone (XLR cable)

PC audio-out (Optional)



PC video-out (Optional)



Telepresence screen 2 (Optional)



Telepresence screen 1

Network

